







What are prepackaged goods?



According to the Law 690 (76/211/ EEC) currently in force, the prepackaged or prepacked item is defined as the combination of a product and the individual package in which it is prepackaged.

A product is prepacked when it is contained in packaging of any type, sealed not in the presence of the purchaser and prepared so that the amount of the product contained has a predetermined value and it can not be altered without opening or clearly changing the same packaging.

The nominal mass or nominal volume of

the contents of a pre-packaged product is the mass or the volume indicated on the packaging and it corresponds to the amount of product that it should contain.

The actual content of a prepackaged product is the amount in terms of mass or volume of product which it in fact contains.

The pre-packedgoods must comply with the provisions of this Law may be marked with the EEC mark and are hereinafter referred to as "pre-packaged EEC".

WHY SHOULD YOU **CHECK** THE WEIGHT OF PREPACKAGED PRODUCTS?

Checking the weight of prepackaged products is essential to ensure the quality of the production process and to protect both the buyer and the manufacturer.

The statistical check isgoverned by

Community Law n. 76/211/EEC and, depending on the Nation, governed by its national legislation in force.

The production checks may be necessary even if not used for legal for trade use but also for internal factory use, to monitor the efficiency of the production cycle. In this case, the check criteria are no longer dictated by law but can be customized to suit your production requirments.







WHAT ARE THE **ADVANTAGES** FOR A PRODUCER TO RUN THESE CONTROL SYSTEMS?

For the traceability of the batch and ensuring a perfect conformity of the manufactured packaging, excludes any complaints of non-compliance.

The quality control of the manufactured batchs in accordance with the laws in force.

The frequent, checking of the manufactured packaging eliminates the risk of overfilling with consequent cost savings from reduced productgivaway.

WHAT HAPPENS IF A DISTRIBUTOR OR THE CONSUMER FINDS A NON-COMPLIANCE?

If a distributor finds a non-conforming product, normally they can refuse the delivery of thegoods with obvious consequinces for the manufacturer. It also threatens to detract from the supplier relationship.

If a consumer finds an underweight package and makes complaint to the competent authority, one will be subject to an investigation which could lead to a case of commercial fraud.



Operationally, how would you perform the checking of the packagedgoods?

THE CHECKING IS DONE BY WEIGHING, USING APPROVED SCALES LEGAL FOR TRADE USE. THE CHOICE OF THE MOST SUITABLE SCALE SHALL BE IN ACCORDANCE WITH THE CRITERIA SET BY THE LAW.

THERE ARE TWO MAIN **METHODS OF CHECKING:**

- The continous checking of the lot/ batch, means that each manufactured package is weighed through an approved scale. Resulting in the elimination of all packaged products that are out of tolerance ensures that the entire lot/batch is fully compliant.
- The statistical sampling, which corresponds to the weighing through an approved scale of a sample of packaged items taken from the total lot/batch during its production, in

times prescribed by the law.

It is advisable in this case to buy an intelligent scale, able to automatically perform all of the calculations and verifications required by the law and to provide in real time the lot/batch results, bygreatly simplifying and speeding up the sampling operations.

In both cases, the producer must retain the data of each lot/batch, in order to certify in case of an inspection or dispute the correct execution of the tests and the compliance of the material sold.





ACCORDING TO WHAT CRITERIA DO YOU CHOOSE THE MOST SUITABLE **SCALE** TO PERFORM THE CHECKING?

The current legislation clearly establishes which reading division the scale must have in order to be suitable to carryout the checking, based on the nominal weight to be checked.

NOMINAL QUANTITY TO WEIGH	READING DIVISION "e" OF THE SCALE
ANY WEIGHT	0.1g
from 10g	0.2g
from 50g	0.5g
from 200g	1g
from 2kg	2g
from 5kg	5g
from 10kg	10g
from 20kg	20g
from 50kg	50g

TABLE 1

For example, if you need to check 500g of pasta packaging, the scale will have a reading division "e" equal to 1g.

IN SUMMARY, **WHAT STEPS** SHOULD THE **MANUFACTURER FOLLOW TO OPERATE IN COMPLIANCE?**



Check if the product concerned is part of the e prepackaged family.



Decide whether to perform an integral or statistical checking.



Buy a weighing scale approved in respect to the features shown in the table 1.



THE SCALES

KDQ - TOUCH SCREEN

Designed for the statistical checking.

The KDQ series scales are the ideal solution for the implementation of full or customised, statistical, legal checking (as provided by the law EEC 76/211).

They are designed specifically in order to offer the customer a quality product with high performance, designed forgreat durability over time.

The KDQ scales are made with a 3590EGT series touch screen indicator and the "T" series precision platforms.



QUALITY MATERIALS

The weight indicator is made in AISI304 stainless steel and is sealled to meet the requirments of IP68 protection classification against ingression of water and dust (waterproof) with a high quality finish.

The "T" series weighing platform is fitted with a high precision aluminum load cell, a stainless steel plate, adjustable feet and level. It is available also in version entirely made by AISI304 stainless steel for food industry.

ADVANCED TECHNOLOGY

The 6-inch touch screen display can make available on a single screen all of the sampling data.

The integrated three way control light shows in real time if the weight is low,good or high, according to the established criteria.

CUSTOM-MADE SOLUTIONS

All products are designed and manufactured in Italy and offer a high degree of configurability and customisation.

In addition, the wide range of available accessories allows to create mobile solutions, able to interact with PC, company network, tablet, smart phone, etc.



APPROVED

FOR LEGAL FOR TRADE USE



The KDQ scales are approved for legal for trade use and offer very high weighing performance, up to $2 \, x$ 6000e multi range.

The advantage this offers to a user is to be able to check prepackagedgoods with different weight ranges using the same scale.

2x3000e 6000e 2x6000e



CUSTOM-MADE SOLUTIONS, FOR YOUR EVERY NEED.





LOADING SURFACE	CAPACITY	APPROVED READING DIVISION "e" for statistical legal/full checking in legal for trade use.	READING DIVISION "d" FOR INTERNAL FACTORY USE for customized / full checking.
230x330	from 3 to 15kg	from 1 to 5g	from 0.1 to 2g
330x330	from 6 to 30kg	from 1 to 10g	from 0.2 to 5g
400x400	from 15 to 150kg	from 2 to 50g	from 0.5 to 20g
400x500	from 30 to 150kg	from 5 to 50g	from 1 to 20g
500x500	from 30 to 150kg	from 5 to 50g	from 1 to 20g
500x600	from 60 to 300kg	from 10 to 100g	from 2 to 50g
600x600	from 60 to 300kg	from 10 to 100g	from 2 to 50g
700x700	from 150 to 600kg	from 50 to 200g	from 10 to 100g




AND IF YOU NEED **GREATER ACCURACY?**

No problem, here **THE SOLUTION** FOR YOU!

Connecting via a serial port a high precision scale, it is possible to check prepackagedgoods of just a fewgrams in accordance with the table 1 shown previously.





TOUCH SCREEN DISPLAY

a valuable help to speed up the checking operations.

Thanks to the 6-inch touch screen display, to check a new sample is very easy:

- The weight is clearly shown in the upper part of the display, along with the tare weight of the prepackaging.
- All data of the current lot are easily accessible at all times.
- The statistical data are available and updated in real time.
- The messagesguide the operator through the entire sample.





28 29 30	500.00 g 500.00 g 500.00 g
END TIME DATE 05/04/2012	16:25
TARGET	500.00 g
T1	15.00 g
T2	30.00 g
AVERAGE WGT.	0 g
STD. DEV.	500.00 g
WGT > T1	0
WGT > T2	0
WGT > T3	0
WGT < T1 WGT < T2	0
WGT < T3	0
WGT OK	30
MAX WGT	500.00 g
MIN WGT	500.00 g
** LOT ACCE	PTED **

The printout is completely customizable.



AVERAGE WGT. STD. DEV.

WGT > T1 WGT > T2

WGT > T3 WGT < T1 WGT < T2

WGT < T3 WGT OK

VOL. MAX VOL. MIN

** LOT REFUSED **

4.50 ml 9.00 ml

2.50 ml

29

100.00 ml

90.67 ml



USB KEY

FOR RECORDING THE WEIGHS. 100% QUALITY, SAFETY, PROFESSIONALITY.



Thanks to the built-in USB key into the weight indicator, each lot/batch, with its weights and statistical report, is automatically and in real time recorded and is available in Excel format for further processing.

The memory key has a storage capacity of 5,000,000 of weighs, so it can record months of continuous work without ever being downloaded to a PC.

The recorded data on the key can be customized and differentiated from the printing on paper: both devices work independently.

					F	G	H		J	K	-	M	N	0
Begin Date	Begin Time	Product	Nom. Quatity (g)	Operator	Lot	Tare (g)	T1 (g)	T2 (g)	Max WGT (g)	Min WGT (g)	Std. Dev.	n° refuse	n° comply	conformity
23/10/12	15:05	Yogurt - conf. 150g	150	4	2012-547	25	6	12	150	150	0	0	30	Accepted
24/10/12	09:00	Yogurt - conf. 500g	500	3	2012-548	30	9	18	500	500	0	0	30	Accepted
25/10/12	10:45	Yogurt - conf. 250g	250	5	2012-549	28	9	18	250	250	0	0	30	Accepted
26/10/12	13:50	Yogurt - conf. 150g	150	2	2012-550	25	6	12	150	150	0	0	30	Accepted
27/10/12	08:24	Yogurt - conf. 500g	500	4	2012-551	30	9	18	500	500	0	0	30	Accepted
28/10/12	11:40	Yogurt - conf. 150g	150	1	2012-552	25	6	12	150	150	0	0	30	Accepted
29/10/12	12:00	Yogurt - conf. 500g	500	3	2012-553	30	9	18	500	500	0	0	30	Accepted
30/10/12	16:50	Yogurt - conf. 500g	500	2	2012-554	30	9	18	500	500	0	0	30	Accepted
31/10/12	08:00	Yogurt - conf. 500g	500	4	2012-555	30	9	18	500	500	0	0	30	Accepted
01/11/12	09:00	Yogurt - conf. 150g	150	1	2012-556	25	6	12	150	150	0	0	30	Accepted
02/11/12	12:26	Yogurt - conf. 250g	250	2	2012-557	28	9	18	250	250	0	0	30	Accepted
03/11/12	13:10	Yogurt - conf. 150g	150	4	2012-558	25	6	12	150	150	0	0	30	Accepted
04/11/12	10:20	Yogurt - conf. 250g	250	3	2012-559	28	9	18	250	250	0	0	30	Accepted
05/11/12	13:27	Yogurt - conf. 150g	150	2	2012-560	25	6	12	150	150	0	0	30	Accepted
06/11/12	14:32	Yogurt - conf. 150g	150	4	2012-547	25	6	12	150	150	0	0	30	Accepted
07/11/12	15:54	Yogurt - conf. 250g	250	3	2012-548	28	9	18	250	250	0	0	30	Accepted
08/11/12	16:25	Yogurt - conf. 500g	500	5	2012-549	30	9	18	500	500	0	0	30	Accepted
09/11/12	12:05	Yogurt - conf. 150g	150	2	2012-550	25	6	12	150	150	0	0	30	Accepted
10/11/12	08:00	Yogurt - conf. 500g	500	4	2012-551	30	9	18	500	500	0	0	30	Accepted
11/11/12	15:00	Yogurt - conf. 150g	150	1	2012-552	25	6	12	150	150	0	0	30	Accepted
12/11/12	09:38	Yogurt - conf. 500g	500	3	2012-553	30	9	18	500	500	0	0	30	Accepted
13/11/12	09:49	Yogurt - conf. 500g	500	2	2012-554	30	9	18	500	500	0	0	30	Accepted
14/11/12	11:57	Yogurt - conf. 500g	500	4	2012-555	30	9	18	500	500	0	0	30	Accepted
15/11/12	10:00	Yogurt - conf. 150g	150	1	2012-556	25	6	12	150	150	0	0	30	Accepted
16/11/12	14:24	Yogurt - conf. 500g	500	2	2012-557	30	9	18	500	500	0	0	30	Accepted
17/11/12	15:13	Yogurt - conf. 150g	150	4	2012-558	25	6	12	150	150	0	0	30	Accepted
18/11/12	16:07	Yogurt - conf. 250g	250	3	2012-559	28	9	18	250	250	0	0	30	Accepted
19/11/12	11:02	Yogurt - conf. 150g	150	2	2012-560	25	6	12	150	150	0	0	30	Accepted
	23/10/12 24/10/12 24/10/12 25/10/12 26/10/12 27/10/12 28/10/12 29/10/12 30/10/12 31/10/12 02/11/12 04/11/12 06/11/12 06/11/12 06/11/12 10/11/12 10/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12 11/11/12	23/10/12 15:05 24/10/12 09:00 24/10/12 09:00 25/10/12 10:45 26/10/12 13:50 27/10/12 08:24 28/10/12 11:40 29/10/12 12:00 30/10/12 16:50 31/10/12 08:00 01/11/12 09:00 02/11/12 12:26 03/11/12 13:10 04/11/12 10:20 05/11/12 13:27 06/11/12 15:54 08/11/12 16:25 09/11/12 15:54 08/11/12 08:00 11/11/12 08:00 11/11/12 10:09:00 11/11/12 10:09:00 11/11/12 10:09:00 11/11/12 15:54 11/11/12 15:54 11/11/12 15:54 11/11/12 09:38 13/11/12 09:38 13/11/12 15:57 15/11/12 11:57 15/11/12 11:57 15/11/12 11:57 15/11/12 11:57 15/11/12 11:57	23/10/12 15:05 Yogurt - conf. 150g 24/10/12 09:00 Yogurt - conf. 250g 26/10/12 10:45 Yogurt - conf. 250g 26/10/12 10:45 Yogurt - conf. 250g 26/10/12 13:50 Yogurt - conf. 250g 26/10/12 13:50 Yogurt - conf. 150g 27/10/12 08:24 Yogurt - conf. 150g 29/10/12 11:40 Yogurt - conf. 500g 30/10/12 16:50 Yogurt - conf. 500g 30/10/12 16:50 Yogurt - conf. 500g 31/10/12 08:00 Yogurt - conf. 500g 01/11/12 09:00 Yogurt - conf. 500g 02/11/12 12:26 Yogurt - conf. 150g 02/11/12 12:26 Yogurt - conf. 150g 03/11/12 10:20 Yogurt - conf. 150g 05/11/12 13:10 Yogurt - conf. 150g 05/11/12 13:27 Yogurt - conf. 150g 05/11/12 13:27 Yogurt - conf. 150g 08/11/12 16:25 Yogurt - conf. 150g 08/11/12 16:25 Yogurt - conf. 500g 10/11/12 08:00 Yogurt - conf. 500g 10/11/12 08:00 Yogurt - conf. 500g 10/11/12 09:38 Yogurt - conf. 500g 11/11/12 09:38 Yogurt - conf. 500g 13/11/12 09:49 Yogurt - conf. 500g 13/11/12 11:57 Yogurt - conf. 500g 13/11/12 11:57 Yogurt - conf. 500g 14/11/12 11:57 Yogurt - conf. 500g 14/11/12 11:57 Yogurt - conf. 500g 14/11/12 11:57 Yogurt - conf. 500g 15/11/12 11:57 Yogurt - conf. 500g 16/11/12 14:24 Yogurt - conf. 500g 16/11/12 14:24 Yogurt - conf. 500g 18/11/12 15:13 Yogurt - conf. 500g 18/11/12 15:13 Yogurt - conf. 500g 18/11/12 15:07 Yogurt - conf. 500g	23/10/12 15:05 Yogurt - conf. 150g 150 24/10/12 09:00 Yogurt - conf. 500g 500 25/10/12 10:45 Yogurt - conf. 250g 250 26/10/12 13:50 Yogurt - conf. 500g 150 27/10/12 08:24 Yogurt - conf. 500g 500 28/10/12 11:40 Yogurt - conf. 500g 500 30/10/12 16:50 Yogurt - conf. 500g 500 31/10/12 08:00 Yogurt - conf. 500g 500 31/10/12 08:00 Yogurt - conf. 500g 500 01/11/12 09:00 Yogurt - conf. 500g 500 03/11/12 19:00 Yogurt - conf. 50g 250 03/11/12 19:20 Yogurt - conf. 150g 150 04/11/12 19:20 Yogurt - conf. 150g 150 05/11/12 13:27 Yogurt - conf. 150g 150 05/11/12 14:32 Yogurt - conf. 150g 250 08/11/12 16:25 Yogurt - conf. 500g 500 08/11/12	23/10/12 15:05 Yogurt - conf. 150g 150 4 24/10/12 09:00 Yogurt - conf. 500g 500 3 25/10/12 10:45 Yogurt - conf. 250g 250 5 26/10/12 13:50 Yogurt - conf. 150g 150 2 27/10/12 08:24 Yogurt - conf. 500g 500 4 28/10/12 11:40 Yogurt - conf. 500g 500 3 30/10/12 16:50 Yogurt - conf. 500g 500 2 31/10/12 08:00 Yogurt - conf. 500g 500 2 01/11/12 09:00 Yogurt - conf. 500g 500 2 02/11/12 12:26 Yogurt - conf. 50g 150 1 04/11/12 10:20 Yogurt - conf. 250g 250 2 05/11/12 13:27 Yogurt - conf. 250g 250 3 05/11/12 14:32 Yogurt - conf. 250g 250 3 08/11/12 16:25 Yogurt - conf. 500g 500 5	23/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 24/10/12 09:00 Yogurt - conf. 500g 500 3 2012-548 25/10/12 10:45 Yogurt - conf. 250g 250 5 2012-549 26/10/12 13:50 Yogurt - conf. 500g 150 2 2012-550 27/10/12 08:24 Yogurt - conf. 500g 500 4 2012-552 28/10/12 11:40 Yogurt - conf. 500g 500 3 2012-553 30/10/12 15:50 Yogurt - conf. 500g 500 3 2012-553 31/10/12 08:00 Yogurt - conf. 500g 500 2 2012-553 31/10/12 09:00 Yogurt - conf. 50g 500 4 2012-556 02/11/12 09:00 Yogurt - conf. 150g 150 1 2012-556 02/11/12 19:26 Yogurt - conf. 150g 150 4 2012-558 04/11/12 10:20 Yogurt - conf. 150g 150 2 2012-558	23/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 25 24/10/12 09:00 Yogurt - conf. 250g 500 3 2012-548 30 25/10/12 10:45 Yogurt - conf. 250g 250 5 2012-549 28 26/10/12 13:50 Yogurt - conf. 150g 150 2 2012-550 25 27/10/12 08:24 Yogurt - conf. 500g 500 4 2012-551 30 28/10/12 11:40 Yogurt - conf. 500g 500 3 2012-553 30 30/10/12 16:50 Yogurt - conf. 500g 500 2 2012-553 30 31/10/12 08:00 Yogurt - conf. 500g 500 2 2012-554 30 31/10/12 09:00 Yogurt - conf. 500g 500 4 2012-556 25 02/11/12 12:26 Yogurt - conf. 150g 150 1 2012-557 28 03/11/12 13:10 Yogurt - conf. 150g 150 4	23/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 25 6 24/10/12 09:00 Yogurt - conf. 500g 500 3 2012-548 30 9 25/10/12 10:45 Yogurt - conf. 250g 250 5 2012-548 30 9 26/10/12 13:50 Yogurt - conf. 150g 150 2 2012-550 25 6 27/10/12 08:24 Yogurt - conf. 150g 150 1 2012-551 30 9 28/10/12 11:40 Yogurt - conf. 150g 150 1 2012-552 6 6 29/10/12 12:00 Yogurt - conf. 500g 500 3 2012-553 30 9 30/10/12 16:50 Yogurt - conf. 500g 500 2 2012-554 30 9 31/10/12 08:00 Yogurt - conf. 500g 500 4 2012-555 30 9 01/11/12 09:00 Yogurt - conf. 150g 150 1 2012-556	23/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 25 6 12 24/10/12 09:00 Yogurt - conf. 500g 500 3 2012-548 30 9 18 25/10/12 10:45 Yogurt - conf. 250g 250 5 2012-550 28 9 18 26/10/12 13:50 Yogurt - conf. 500g 500 4 2012-550 25 6 12 27/10/12 08:24 Yogurt - conf. 500g 500 4 2012-551 30 9 18 28/10/12 11:40 Yogurt - conf. 500g 500 3 2012-553 30 9 18 30/10/12 15:50 Yogurt - conf. 500g 500 2 2012-553 30 9 18 31/10/12 08:00 Yogurt - conf. 500g 500 2 2012-553 30 9 18 01/11/12 09:00 Yogurt - conf. 500g 500 2 2012-556 25 6	23/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 25 6 12 150 24/10/12 09:00 Yogurt - conf. 500g 500 3 2012-548 30 9 18 500 25/10/12 10:45 Yogurt - conf. 250g 250 5 2012-550 25 6 12 150 26/10/12 13:50 Yogurt - conf. 500g 500 4 2012-551 30 9 18 500 28/10/12 11:40 Yogurt - conf. 150g 150 1 2012-551 30 9 18 500 29/10/12 12:00 Yogurt - conf. 500g 500 3 2012-553 30 9 18 500 30/10/12 16:50 Yogurt - conf. 500g 500 2 2012-553 30 9 18 500 31/10/12 08:00 Yogurt - conf. 500g 500 4 2012-553 30 9 18 500 01/11/12	23/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 25 6 12 150 150 24/10/12 09:00 Yogurt - conf. 500g 500 3 2012-548 30 9 18 500 500 25/10/12 10:45 Yogurt - conf. 150g 250 5 2012-549 28 9 18 250 250 26/10/12 13:50 Yogurt - conf. 150g 150 2 2012-550 25 6 12 150 150 27/10/12 08:24 Yogurt - conf. 500g 500 4 2012-551 30 9 18 500 500 28/10/12 11:40 Yogurt - conf. 500g 500 3 2012-553 30 9 18 500 500 29/10/12 12:00 Yogurt - conf. 500g 500 2 2012-553 30 9 18 500 500 31/10/12 08:00 Yogurt - conf. 500g 500 2	23/10/12 15:05	23/10/12 15:05	13/10/12 15:05 Yogurt - conf. 150g 150 4 2012-547 25 6 12 150 150 0 0 30



WEICHECK

THE PC PROGRAM
FOR THE SUPERVISION OF THE CHECKING
OF YOUR PRODUCTION LINES.





- Databases of products, containers, production, statistics, operators, tolerance systems, additional tares, sampling plans (associable to each article) and quality levels.
- Designed for statistical analysis
 based on the tables of the law
 690/78 and from those in the UNI
 ISO 2859 norms or based on the
 tables directly configured by the user.
- Management of a number of production lines (independent weighing stations), allowing to maintain an updated database

- containing all the articles data, the productions, the accepted or refused lots/batch, the operators and the statistical data of each sample.
- Management of the fiscal memory on the weight indicator thatguarantees the approval of the system.
- Reporting of end of lot/batch
 and processing / printing of the
 overall "Judgment" with details on
 "Acceptance" or "Rejection" of the
 lot/batch according to the assigned
 sampling plan, the tolerance system,

- and the quality level to be achieved; recording of a historical weighs database for further processing.
- Checking of production progress in real time with the help of the distributiongraph of the samples within the range and the detection synoptic.
- Export / import into the program
 of the customer data or databases
 based on the provided specifications.







A RICE LAKE WEIGHING SYSTEMS COMPANY

COMPANY HEADQUARTERS

Via Della Fisica, 20 41042 Spezzano di Fiorano Modena · Italy Tel. +39.0536 843418

SERVICE ASSISTANCE

Via Dell'Elettronica, 15 41042 Spezzano di Fiorano Modena • Italy Tel. +39.0536 921784

OTHER DINI ARGEO LOCATIONS

DINI ARGEO WEIGHING INSTRUMENTS Ltd

DINI ARGEO UK Ltd United Kingdom

DINI ARGEO FRANCE sarl France

DINI ARGEO GMBH Germany

SALES SERVICE AND TECHNICAL ASSISTANCE

WHY CHOOSE DINI ARGEO?



WORLDWIDE SERVICE AND SHIPPING

International group with offices in America, Europe, India, China, Mexico and Oceania, over 900 employees and a network of specialised partners in 130 countries worldwide.



FAST SHIPPING

Dini Argeo always keeps complete systems in stock that can be shipped quickly.



MADE IN ITALY

Dini Argeo weighing solutions are made in Italy and guarantee the highest quality standards.



